



# ACCESS CONTROL AND ACCESSORIES

## Transformer/Rectifier/ Piezo Horn



**4605  
Transformer**

**4606  
Transformer**




**4603 Rectifier**

### ▼ 4605 Transformer

Converts 120VAC to 12VAC/24VAC. Rated 40 Volt-amp output assures plenty of power for strike release.

### ▼ 4606 Transformer

Converts 120VAC current to 24VAC. Plugs into standard wall outlet.



Provides for audible indication of when a DC strike is energized. Operates with 12 VDC, 16 VDC or 24 VDC strikes.



# Options and Accessories

## RECTIFIER

### 4603 Rectifier

Converts low voltage AC current to DC of same voltage. Installs in low voltage line between transformer and strike. Full wave bridge type. Rated 2 amps. (200 PIV).

## PIEZO HORN

### 29-0218

Provides for audible indication of when a DC strike is energized. Operates with 12 VDC, 16 VDC or 24 VDC strikes.

## OTHER POWER SUPPLIES

### PS-1

Provides filtered and regulated voltage output to power electric strikes, magnetic locks or other access control devices. Output is selectable in the field for 12 or 24 VDC. Charging circuit is built in for battery backup power with 12 or 24 VDC operation. LED on circuit board indicates power input.

## TRANSFORMER

### 4605

Converts 120VAC to 12VAC/24VAC. Rated 40 Volt-amp output assures plenty of power for strike release.

### 4606

Converts 120VAC current to 24VAC. Plugs into standard wall outlet.